


# FLOW RACK: DEFINE THE HEIGHT OF THE LEVELS ACCORDING TO THE ERGONOMIC ZONE

The height of the levels should always vary from a minimum of 24 in. up to a maximum of 60 in.



**VISIT [FLEXPIPEINC.COM](http://FLEXPIPEINC.COM)**  
FOR MORE ASSEMBLY TIPS AND CREATIVES PICTURES!