


# INCREASE LOADING CAPACITY OF YOUR FLOW RACKS

Here are two options to increase your flow rack's capacity:

- **Add numerous conveyor tracks to spread the load,**
- **Double the front and rear tube support.**



---

**VISIT [FLEXPIPEINC.COM](https://flexpipeinc.com)**

**FOR MORE ASSEMBLY TIPS AND CREATIVES PICTURES!**